



FR03002P - Ferrari 360, 430, 575, 599, 612 lower ball joint installation instructions

Parts needed:	Tools required:
✓ FR03002P – Ferrari 360, 430, 575, 599, 612 lower ball joint	✓ Hydraulic press ✓ Grease ✓ FR63002P - (set includes tools A & B) ✓ FR98003P – Ferrari ball joint adhesive

Difficulty level:



Procedure:

Remove old ball joints and clean the wishbone.

Ball joint installation:

1. Put the dust cover into the wishbone rabbet (one side only). For easier assembly grease the edge of the dust cover:




2. Clean and degrease ball joint surface and apply Ferrari ball joints adhesive [FR98003P](#) on the blue marked area:



3. Place the wishbone on tool B. Turn tool B with the arrow pointing up.



4. Place tool A on the ball joint. Turn tool A with the arrow pointing down.



5. Carefully press the ball joint into the wishbone – all the way to the previously assembled dust cover.





6. Place the second dust cover on the ball joint. The ball joint should have dust covers on both sides. For easier assembly grease the edge of the dust cover:



7. Check both dust covers. They should be fitted nicely on the neck of the ball joint.



Thank you for your purchase!



www.prekom-usa.com

www.prekom.si

